


FIG. 1



GOLFBREIKSCHAKELAAR 5 STANDEN:  
 KG1, KG2, KG3, M, 5, GRAM,  
 GETEKEND IN STAND KG1.

WAVENANGE SWITCH 5 POSITIONS:  
 SW1, SW2, SW3, MW, GRAM,  
 SHOWN IN POSITION SW1.


CONDENSERS  
 CONDENSATOREN

CERAMIC  
 KERAMISCHE

PAPER  
 PAPIER

TRIMMER

WEERSTANDEN  
 RESISTORS



- B1 = ECH 42
- B2 = EAF 42
- B3 = EBC 41
- B4 = EL 41
- B5 = AZ 41

C	1	2, T/M 7	8, 10, 11, 45, 12, 13, 14, 15, 16	17, T/M 24	25, 26, 9	27	28, 29, 30	31, T/M 35	36, 44, 37	43, 38, 39, 40	41, 42
R	1	1, T/M 4	5, 6	20, T/M 29	30, 31, 32, 33	8, 7, 9	10, T/M 15	16, T/M 20	21, T/M 27	28, 29, 30	31, 32
S	1	2, T/M 11, 12, T/M 19								38, T/M 42	43