


FIG. 1



N	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55
C	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55

WAVERANGE - SWITCH DRAWN IN POSITION F.M.
 BASS SWITCH DRAWN IN POSITION NORMAL.
 SELECTIVITY - SWITCH 3 POSITIONS, 1 SMALL, 2 NORMAL, 3 BROAD (P).
 DRAWN IN POSITION NORMAL.
 AERIAL SWITCH DRAWN IN POSITION OUTDOOR AERIAL(K)

