




GOLFEREKSCHAKELAAR IN STAND FM
 COMMUTEUR DE GAMMES D'ONDES DANS LA POS. FM
 WELLENBEREIKSCHAKELER IN STAND FM



DE SPANNINGEN ZIJN GEMETEN T. O. V. J.
 LES TENSIONS SONT MESUREES ENVERS J.
 DIE SPANNINGEN SIND GEMESSEN GEGEN J.

ERRES RA 665

C	R	S	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60				
31	88	35	33	34	4	101	38	39	5	7	6	18	41	2	8	12	10	42	11	45	43	13	14	15	16	51	86	95	52	98	97	85	97	56	80	67	65	61	70	71	72	73	93	75	74	94	77	79	94	55	78	82	81	50	54	50	51	34	35	36	37	40	42	43	45	38
48	47	12	13	15	60	1	13	3	2	14	3	4	15	5	6	7	16	17	21	20	27	6	7	8	9	23	23	26	26	26	50	28	31	28	33	28	31	32	32	33	39	38	39	40	42	41	42	43	45	38	38	39	40	41	42	43	45	38	38	39	40	41	42	43	45	38



C	101	2	76	91	86	80	95	40	43	70	44	48	89	72	58	94	57	63	69	68	73	33	34	75	35	83	79	77	78	84				
	101a	2a	31	88	97	81	39	38	32	40	41	67	71	56	45	53	58	94	64	63	69	68	73	93	74	55	83	79	77	78	84			
R	50				13		14	40	16	39	15	23	22	42	51	36	37	26	33	35	34	28	29	30	43	48	45	47	44	52	60	53	54	38